

Bridge load rating FAQ

This page is devoted to **frequently asked questions** (FAQ) related to [bridge load rating](#).

Can the bridge modeler perform bridge load rating?

Answer: Yes, the [bridge modeler](#) can perform load-rating for precast I-girder and reinforced-concrete box-girder bridge superstructures. Load ratings for composite steel-girder and other types of bridges may be manually calculated using resistance data generated using the software and the live load and dead load demands.