

# Manual modification of bridge bearings

## Tutorial

|              |  |
|--------------|--|
| Name:        | Manual modification of bridge bearings   |
| Description: | Guidelines for the manual modification of bridge bearings automatically created by the bridge modeler. |
| Program:     | SAP2000  |
| Version:     | 12.0.2   |
| Model ID:    | na   |
|              |  |
|              |  |
|              |  |



This tutorial was originally for the bridge modeler in SAP2000, but the same concept also applies to CSiBridge.

The purpose of this tutorial is to demonstrate **manual modification of bridge bearings**. The [bridge modeler](#) automatically generates bearings. Modification is then done outside of the bridge modeler. This tutorial will follow a two-span continuous reinforced-concrete box-girder bridge with four web sections, supported by two bearings at each substructure location. These bearings are centered between each pair of exterior and interior girders. Users may manually modify start-abutment bearing locations through the following process:

- Use the Bridge > Update Linked Bridge Model menu to update the structural model.
- Uncheck Bridge > Auto Update Linked Bridge Objects to prevent the bridge modeler from overwriting manual changes.
- Delete the interior-girder bearing [links](#) and associated [joints](#) automatically produced, as shown in Figure 1:




Figure 1 - Delete interior bearings

- Use the Edit > Move option to move the exterior-girder bearing links and associated joints to the location desired along the transverse direction, as shown in Figure 2:




Figure 2 - Move exterior bearings

- Modify the bearing-link properties as necessary.

Additionally, please note that the bottom link connects the **bent cap** to a joint at the **bearing**. These link properties represent those of the bearing. The top link creates a bearing joint at the bottom of the superstructure. The properties assigned to this link simulate a **rigid** connection. Further, the body constraint BOBJ-1 connects the start joint of each superstructure girder to joints at the bottom of the superstructure, located just above the bearings, as shown in Figure 3:




Figure 3 - Bridge bearings

- Users may then repeat the procedures of this tutorial for the interior bent and end abutment.